





Wi-Fi Chime








Power Plug

Overview

1. Status Indicator
2. Reset Button
3. Power Plug
4. Release Tab
5. Device QR Code



Status Indicator

	Device ready
	Ready for network connection
	Device malfunction*
	Network connection failed*
	Firmware update in progress

*Try resetting your Chime by holding down the reset button.



IMPORTANT!

- Ensure you are on a 2.4 GHz Wi-Fi connection.
- Ensure your Video Doorbell and Wi-Fi Chime have the latest firmware version in the device settings.

Setup


1. Download the **Lorex** app.



2. (A) Attach the plug, and then (B) push the release tab inward to lock the plug.

Note: To remove the power plug, lift up on the release tab.

3. Plug your Chime into an outlet.
4. Tap **+** in the app, and then follow the in-app instructions to add your Chime.



Need help?

For additional support material, scan the QR code or visit help.lorex.com/ACCHM2.

Please see our full Terms of Service and Limited Hardware Warranty Policy at lorex.com/warranty.



Copyright © 2023 Lorex Technology Inc.

As our products are subject to continuous improvement, Lorex reserves the right to modify product design, specifications and prices, without notice and without incurring any obligation. E&OE. All rights reserved.